


# Hx5xx firmware update how to...

Firmware update procedure:

1. Download new firmware from manufactures web pages, install latest TSensor software. Unpack downloaded archive with firmware.
2. Turn on device and connect Ethernet connector.
3. Run TSensor with parameter **/service** (e.g. **C:\Program files \Cometloggers \TSensor\TSensor.exe /service**)
4. Open menu for firmware update. Insert device IP address and enter new firmware (**ROM file**) and new web pages (**COB file**) if necessary. Press button **Update**.



5. Please wait while new firmware is uploading. This operation takes approx. one minute. After successfully upload, will be shown following message.

